


Freud Router Bit: 99-270



Steps To Produce A Divided Lite Door

(mortise should be 1/2 or 2/3 the width of the rail)

